


Easy 5-Step Guide to using the document camera

- 1) Make sure the AverVision 300p is plugged in and turned on; the power button is on the left side of the unit.
- 2) There are 2 VGA connectors on the right side of the AverVision 300p. Connect the LCD Projector VGA cable to the left-hand (frontmost) VGA connector.
- 3) Set the AverVision 300p to Camera Mode (push Camera button) and select VGA output (push VGA/TV button). The LED just above the PC button should be GREEN.
- 4) Turn on the LCD projector
- 5) Position your document under the camera head. You should now be able to see your document on the projection screen. Use the Zoom +/- buttons on the right side of the Control Panel to zoom the picture in or out.

In somewhat more detail:

AverVision 300p Quick Reference

Touch Button Control Panel The control panel provides access to commonly used functions.




(1) CAMERA MODE	Switch to Camera Mode, display image from built-in camera
(2) PC MODE	Switch to PC mode, display image from RGB input port
(3) PLAYBACK MODE	Switch to Playback mode & toggle to display 80 images
(4) VGA/TV	Select VGA output or TV (composite or s-video) output
(5) EFFECT	Convert/display video: BW, Negative or Color (camera mode only)
(6) FREEZE	Toggle to pause or resume the camera
(7) CAP/DEL	Photograph an image (stored at 1024x768 resolution) 80 images can be stored In Playback Mode, press this button to delete the saved image
(8) MENU	Call up and exit OSD main and sub menus
(9) ZOOM +/-	Playback mode: zoom picture in or out digitally Camera mode: zoom picture in or out 2x optical zoom, followed by 16x digital zoom
(10) ▲ ▼ ◀ ▶	Use ◀ ▶ ▲ ▼ to make selections/adjustments Also use ▶ to enter sub-menus Use ◀ ▶ ▲ ▼ to make selections in 80-thumbnail images, and press (7) to view the selected image


LED Panel The LED on the front panel of AverVision 300p indicates the status of the unit.
Green: VGA output **Red:** TV output **Orange:** standby mode.

(over)


Projector Hookup The AverVision 300p enables you to display a presentation on an LCD projector. Connect the projector VGA cable to the document camera as shown.




Light and Document Positioning Pointer The AverVision 300p has 4 laser positioning pointers that define the viewing area, enabling you to correctly center an object under the camera's viewing area. 3 various light and laser position pointer settings are provided as follows.



Camera Head The camera head can be rotated 135 degrees from left to right. You can also manually adjust the focus from here to improve the quality of the pictures.



Mechanical Arm AverVision 300p features a mechanical arm that enables you to project an image to its full height for full A4 paper landscape viewing.



For more info: <https://wiki.lepp.cornell.edu/lepp/bin/view/Computing/AudioVisualEquipment>